

TonerKits

do-it-yourself toner refill kits

Request a detailed color copy of these instructions by email at support@tonerkits.com

Standard Refill Instructions

E360 sf1.0

Dell 330-2647/2648/2649/2650, 330-2664/2665/2666/2667
Lexmark E260A11A/21A, E360H11A/21A
Lexmark X264A21G/H21G

1) Install the new chip the same way the old chip was installed in the location shown. CAUTION - All chips are static sensitive and can be damaged if subjected to a static discharge.

Note: If there is no screw holding the chip in place, then it is being held by adhesive and can be gently pried off.

2) Use a small flat blade screwdriver to gently pry off the encoder wheel from behind.

3) Use a pair of needle nose pliers or small flat blade screwdriver to pull or pry out the fill hole plug.

4) Shake the toner bottle well to aerate and loosen the toner. Then remove the cap and install the pouring spout. Slowly pour in the new toner. The whole bottle should be used so the toner level matches the chip. Try to avoid squeezing the bottle as it may cause toner to blow out all over the cartridge. Once refilling is complete, reinstall the fill hole plug and encoder wheel.

5) Gently shake the cartridge side to side to level the toner. Then reinstall it in the machine and run some test prints.

Fast Online Ordering Available 24/7
www.tonerkits.com

