

# TonerKits

## do-it-yourself toner refill kits

Request a detailed color copy of these instructions by email at [support@tonerkits.com](mailto:support@tonerkits.com)

### QuikFil Instructions

LBPEX qf1.0

**Apple M2473G/A**  
**Brother TN9000**  
**Canon EPE, R741003**  
**HP 92298A/98X, C3973A**

1) Use our Universal Hole Tool or other melting device to make a 3/4 inch fill hole in the location shown. Do not allow any small bits of plastic to fall into the cartridge. If using our hole tool, read the operating instructions that came with it.

2) Shake the toner bottle well to aerate and loosen the toner. Then remove the cap and install the pouring spout. Slowly pour in the whole bottle of new toner. Try to avoid squeezing the bottle as it may cause toner to blow out all over the cartridge.

3) Once refilling is complete, clean the area around the fill hole and seal it with a two inch piece of the foil tape that came with the kit. Smooth the tape out well to make a leak proof seal.

4) Gently shake the cartridge side to side to level the toner. Then reinstall it in the machine and run some test prints.

**Note:** HP 92298A cartridge shown but all other cartridges listed above are of the same design and are refilled the same way.



3/4" hole cutter tip



make fill hole here

**Fast Online Ordering Available 24/7**

**[www.tonerkits.com](http://www.tonerkits.com)**