

TonerKits

do-it-yourself toner refill kits

Request a detailed color copy of these instructions by email at support@tonerkits.com

QuikFil Instructions

ML2850 qf3.0

Samsung MLD2850A/B MLTD209L/S MLTD2092L/S

1) Use our Universal Hole Tool or other melting device to make a 3/4 inch fill hole in the location shown. Do not allow any small bits of plastic to fall into the cartridge. If using our hole tool, read the operating instructions that came with it.

2) Shake the toner bottle well to aerate and loosen the toner. Then remove the cap and install the pouring spout. Slowly pour in the whole bottle of new toner. Try to avoid squeezing the bottle as it may cause toner to blow out all over the cartridge.

3) Once refilling is complete, clean the area around the fill hole and seal it with a two inch piece of the foil tape that came with the kit. Smooth the tape out well to make a leak proof seal.

4) Chip replacement: Install the reset chip the same way the old chip was installed in the location shown. **CAUTION** - All chips are static sensitive and can be damaged if subjected to a static discharge.

Accessing the Chip: Carefully pry the chip cover off the plastic rivet heads with a small flat blade screwdriver and remove the cover. Once the reset chip is installed, place the cover back on. If the chip cover or rivets break while attempting to pry them apart, just secure the cover with a piece of the foil tape that came with the kit. Make sure the chip cover is completely in place so it does not obstruct the chip's contacts. Position the tape as shown (dotted line) so it does not obstruct the slots in the cover.

5) Gently shake the cartridge side to side to level the toner. Then reinstall it in the machine and run some test prints.



Fast Online Ordering 24/7...www.tonerkits.com