

TonerKits

do-it-yourself toner refill kits

Refilling Instructions

Canon 7833A001 8489A001 8955A001
HP C7115A C7115X Q2613A Q2613X
HP Q2624A

1) Use our Universal Hole Tool or other melting device to make a 3/4 inch fill hole in the location shown. Do not allow any small bits of plastic to fall into the cartridge. If using our hole tool, read the operating instructions that came with it.

2) Shake the toner bottle well to aerate and loosen the toner. Then remove the cap and install the pouring spout. Slowly pour in the whole bottle of new toner. Try to avoid squeezing the bottle as it may cause toner to blow out all over the cartridge.

3) Once refilling is complete, clean the area around the fill hole and seal it with a two inch piece of the foil tape that came with the kit. Smooth the tape out well to make a leak proof seal.

4) Gently shake the cartridge side to side to level the toner. Then reinstall it in the machine and run some test prints.

Note: HP C7115A cartridge shown but all other cartridges listed above are of the same design and are refilled the same way. Replacing the reset chip is optional for the HP Q2613A/13X cartridges. If a new chip is not installed, the printer will continue to display a low toner message after the cartridge has been refilled but it will not interfere with the normal operation of the printer. If a new chip is being installed, there is no special trick to it, simply remove the old one and install the new one the same way.



Fast Online Ordering Available 24/7 www.tonerkits.com